


Shear = (negative)Slope of Bending moment (i.e. $V = dM/dx$)



Shear = (negative)Slope of Bending moment (i.e. $V = dM/dx$)

